## **Slimline Range** SM 550-FF

#### Vibratory Check Screener in 550mm Diameter

The 550-FF model can be used as a simple means of check sieving into bins or containers. It is primarily designed to be fed under gravity within new or existing production lines, to screen product into a static weigh bin, big bag, convey line or hopper.

The basic unit will locate within a confined area to provide for retrospective fitting into systems that previously had no sieving equipment. Used with the optional wheeled base assembly, it makes an ideal arrangement to sieve ingredients in small or large batch volumes.

#### **INDUSTRIES**











Additive

Manufacturing

T O

ê n

ጠ

0

by farleygr

#### **FEATURES**

- Mobile stands available for greater flexibility, which can be designed to suit installation
- Constructed from FDA compliant materials
- No tool, quick change screens
- Easy clean design, no crevices
- Dust & hose proof IP67

All stainless steel contact parts

Noise level less than 70 dBA when in use

- ATEX approved on all sizes as standard
- Can be fitted into sack tipping stations to • provide for a dust free, clean operating area
- Vacuum / pressure transfer models available

#### TYPICAL MATERIALS

Recycling

- Spices
- Cosmetics
- Seeds
- Most powders /
- granular products Liquid separation
- Flour •
- Crystal sugar • Starch
- Cocoa
- Wet or dry
  - applications

#### **PRODUCT OPTIONS**

#### Machine configurations\*

- Open top version with reduced or extended height top gallery
- Sack tip entry with Safety grid
- Inlet diaphragm seal
- Underscreen magnet assy
- 304SS tubular handles to clamps
- Upgrade to Internal: ATEX 20 II • 1D External: ATEX 22 II 3D
  - \*More options available on request

Έx

- Cone dispersion type inlet Weirflo type inlet Jacob, BFM and Triclamp inlet / outlet Oversize discharge outlet with weir plate Tubular 'C' type frame
- Ultrasonic uparade
- Safety interlock

#### **Finishes** available

- External mirror polish to top gallery <0.8Ra
- Dressing of all external welds (with standard mirror polish)
- Pharmaceutical mirror polish <0.25Ra & dressing of all external welds
- Passivation after polish
- Viwateq/Sublimotion finish whole machine
- Upgrade from earth clips to external direct mesh earthing system

## **CERTIFIED TECHNOLOGY**

Farleygreene Limited. Unit 2, Hatch Industrial Park, Greywell Road, Mapledurwell, Hampshire, RG24 7NG. United Kingdom. t +44 (0) 1256 474 547 f +44 (0) 1256 329 596 e info@farleygreene.com www.farleygreene.com









# **Slimline Range**

## SM 950-ST

#### Vibratory Check Screener in 950mm Diameter

The 950-ST is primarily designed to be fed under gravity within new or existing production lines, to screen product into a static weigh bin, big bag, convey line or hopper.

The 'Slimline' can be located above the inlet to provide an efficient and fast means of ensuring product reliability. The basic unit will locate within a confined area to provide for retrospective fitting into systems that previously had no sieving equipment.







Pharmaceutica Chemico





1





р 2

farleyg

gre

Φ

ጠ

Additive Manufacturing

#### **FEATURES**

- Can be fitted into sack tipping stations to provide for a dust free, clean operating area
- Constructed from FDA compliant materials
- No tool, quick change screens
- Easy clean design, no crevices
- Vacuum / pressure transfer models available

(Ex

ATEX

#### • Noise level less than 70 dBA when in use

- All stainless steel contact parts
- ATEX approved on all sizes as standard •
- Dust & hose proof IP67

#### **TYPICAL MATERIALS**

Recycling

#### Spices Cosmetics

- Seeds
- Most powders/
- granular products
- Liquid separation
- Flour
- Crystal sugar
- Starch
- Cocoa
- Wet or dry applications

### **PRODUCT OPTIONS**

#### Machine configurations\*

- Upgrade to Internal: ATEX 20 II 1D External: ATEX 22 II 3D
- 304SS tubular handles to clamps
- Easy clean drawer magnet assy
- Cone dispersion type inlet
- Weirflo type inlet
- Vision port

- inlet / outlet
- weir plate
- Collection bin

- Safety interlock



#### Finishes available

- External mirror polish to top gallery • < 0.8Ra
- Dressing of all external welds (with standard mirror polish)
- Pharmaceutical mirror polish < 0.25Ra & dressing of all external welds
- Passivation after polish
- Viwatea/Sublimotion finish -whole machine
- Upgrade from earth clips to external direct mesh earthing system

## **CERTIFIED TECHNOLOGY** 및 **FDA ( E 兆** 🐼

Farleygreene Limited. Unit 2, Hatch Industrial Park, Greywell Road, Mapledurwell, Hampshire, RG24 7NG. United Kingdom. t +44 (0) 1256 474 547 f +44 (0) 1256 329 596 e info@farleygreene.com www.farleygreene.com





Support frame assy

Ultrasonic upgrade







# **Slimline Range**

## SM 1250-ST

#### Vibratory Check Screener in 1250mm diameter

The 1250-ST is primarily designed to be fed under gravity within new or existing production lines, to screen product into a static weigh bin, big bag, convey line or hopper.

This larger unit is technically similar to the SM550/950 models

but are designed for very high throughput requirements and have some small design changes due to the size and weight of the components. Maximum consideration is given in the design to ensure these large units can be stripped down by operators.

#### **INDUSTRIES**



٤x

ATEX



•









σ <

Ω 

ILI O

Q Г Ф

ê N

ጠ





#### **FEATURES**

- Support frames available, which can be designed to suit installation
- Constructed from FDA compliant materials
- No tool, quick change screens
- Easy clean design, no crevices
- Dust & hose proof IP67

- Noise level less than 70 dBA when in use All stainless steel contact parts
- ATEX approved on all sizes as standard
- Vacuum / pressure transfer models available

#### **TYPICAL MATERIALS**

- . Spices
- Cosmetics Seeds
- Most powders/
- granular products Liquid separation
- Flour

•

- Crystal sugar
- Starch
- Cocoa
  - Wet or dry applications

### **PRODUCT OPTIONS**

#### Machine configurations\*

- Upgrade to Internal: ATEX 20 II . 1D External: ATEX 22 II 3D
- 304SS tubular handles to clamps
  - Easy clean drawer magnet assy
- Cone dispersion type inlet
- Weirflo type inlet
- Vision port
  - \*More options available on request

- Jacob, BFM and Triclamp outlet end
- Jacob, BFM and Triclamp inlet end
- Oversize discharge outlet with weir plate
- Support frame assv
- Collection bin
- Ultrasonic upgrade
- Safety interlock

#### Finishes available

- External mirror polish to top gallery < 0.8Ra
- Dressing of all external welds (with standard mirror polish)
- Pharmaceutical mirror polish < 0.25Ra & dressing of all external welds
- Passivation after polish
- Viwateg/Sublimotion finish -whole machine
- Upgrade from earth clips to external direct mesh earthing system

## **CERTIFIED TECHNOLOGY** 못" ▶ ★ ★ ★ ★

Farleygreene Limited. Unit 2, Hatch Industrial Park, Greywell Road, Mapledurwell, Hampshire, RG24 7NG. United Kingdom. t +44 (0) 1256 474 547 f +44 (0) 1256 329 596 e info@farleygreene.com www.farleygreene.com







Additive Manufacturing

**Reclamation &** Recycling



## **Slimline Range** SM 1550-ST

#### **Vibratory Check Screener** in 1550mm Diameter

The 1550-ST is primarily designed to be fed under gravity within new or existing production lines, to screen product into a static weigh bin, big bag, convey line or hopper.

This larger unit is technically similar to the SM550/950 models

but are designed for very high throughput requirements and have some small design changes due to the size and weight of the components. Maximum consideration is given in the design to ensure these large units can be stripped down by operators.

#### **INDUSTRIES**



(Ex)

ATEX











р 2

farleyg

I T O

e n

Ω

#### Additive Manufacturing

#### **FEATURES**

- Support frames available, which can be designed to suit installation
- Constructed from FDA compliant materials
- No tool, quick change screens
- Easy clean design, no crevices

#### **PRODUCT OPTIONS**

#### Machine configurations\*

- Upgrade to Internal: ATEX 20 II 1D External: ATEX 22 II 3D
- 304SS tubular handles to clamps
- Easy clean drawer magnet assy •
- Cone dispersion type inlet
- Weirflo type inlet
- Vision port
- \*More options available on request

- Jacob, BFM and Triclamp outlet end
- Jacob, BFM and Triclamp inlet end
- Oversize discharge outlet with weir plate
- Support frame assy
- Collection bin
- Ultrasonic upgrade
- Safety interlock

- ATEX approved on all sizes as standard
- Vacuum / pressure transfer models available
- Noise level less than 70 dBA when in use

#### TYPICAL MATERIALS

Recycling

- Spices Cosmetics
- Seeds
- Most powders/
- granular products
- Liquid separation

- - Starch

Flour

- Cocoa
  - Wet or dry applications

Crystal sugar

#### **Finishes available**

- External mirror polish to top gallery < 0.8Ra
- Dressing of all external welds (with standard mirror polish)
- Pharmaceutical mirror polish <0.25Ra & dressing of all external welds
- Passivation after polish
- Viwateg/Sublimotion finish whole machine
- Upgrade from earth clips to external direct mesh earthing system

## **CERTIFIED TECHNOLOGY**

Farleygreene Limited. Unit 2, Hatch Industrial Park, Greywell Road, Mapledurwell, Hampshire, RG24 7NG. United Kingdom. t +44 (0) 1256 474 547 f +44 (0) 1256 329 596 e info@farleygreene.com www.farleygreene.com







lamation &

6																			L TO CHANGE
020202020	& 950-ST	17		SM950-ST (mm)	755	665	1 50 (OPTIONAL)	150 - 900	100/150 (OPTIONAL)	150 - 400	485	65mm LIS CAN BE FITED ADD 50mm TO 'G' DIM NS TO INLET/OUTLET	SM950-ST	110/240/380-460	50 / 60 hz	0.9 kw	1/3	YES EX	ALL DIMS. ARE APPROX. NOT TO BE USED FOR FINAL PLANNING. FULL DRAWINGS CAN BE SUPPLIED ON REQUEST. SUBJECT TO CHANGE AT ANY TIME.
5	SM SLIMLINE 550-FF & 950-ST			SM550-FF (mm)	510	415	100 (OPIIONAL)	150 - 530	100 (OPIONAL)	150 - 300	400 *	SCREEN DIAMETER = 565mm & 965mm BESPOKE FRAMES AVAILABLE - BFMJACOB ENDS CAN BE FITTED *FOR SM550-FF WITH UNDERSCREEN MAGNET ASSY ADD 50mm TO 'G' DIM ALLOW min. 50mm FOR FLEXIBLE CONNECTIONS TO INLET/OUTLET	SM550-FF	110/240/380-460	50 / 60 hz	0.35 kw	1/3	YES <b>(EX)</b>	FOR FINAL PLANNING, FULL DRAWINGS
4				DIMENSION	А	B	υ	٩	Ш		Q	BESPOKE +FOR SM560-FI ALLOW min	ELECTRICAL	VOLIAGE	FREQUENCY	POWER	PHASE	ATEX	PPROX. NOT TO BE USED F
													20						DIMS. ARE A
00000000000													9 9 9						ALL DIMS. ARE A
																			ALL DIMS. ARE A
																			owwarscone c

 $\triangleleft$ 

( )

0 0

ш

0 (

00

C

220

Ω

ALL DIMS. ARE APPROX. NOT TO BE USED FOR FINAL PLANNING. FULL DRAWINGS CAN BE SUPPLIED ON REQUEST. SUBJECT TO CHANGE AT ANY TIME. • 6 SM1550-ST (mm) 110/240/380-460 SM1550-ST 150 (OPTIONAL) 150 - 900 150 - 600 50 / 60 hz ALLOW min. 50mm FOR FLEXIBLE CONNECTIONS TO INLET/OUTLET BESPOKE FRAMES AVAILABLE - BFM/JACOB ENDS CAN BE FITTED SM SLIMLINE 1250-ST & 1550-ST SCREEN DIAMETER = 1165mm & 1465mm NIN STATISTICS SM1250-ST (mm) YES  $\langle \underline{\mathsf{S}}_{\mathsf{X}} \rangle$ 110/240/380-460 SM1250-ST 150 - 900 150 - 600 50 / 60 hz 0.9 kw 842 DIMENSION ELECTRICAL FREQUENCY VOLTAGE POWER PHASE 4 (i+ T ØΕ 2 Þ af I ALE .

0

4